

700cc Grease Cartridge



◆Order Code

Voluci Couc							
Order Code	Grease Type	Grease Viscosity	Minimum Order Quantity Requirement				
I01D0021	Mobil EP000	NLGI 000					
I01D0012	Mobil EP0	NLGI 0					
I01D0013	Mobil EP1	NLGI 1	100				

◆Features

- 1. 700cc grease cartridge is suitable for KACP-07, KABP-07, KGCP-07, KGNP-07, KGNP-07, KGNBP-07, and POM-AP-07 types grease lubricators.
- 2. Standard 700cc grease cartridge is filled with Mobil grease. Please specify when you place an order if you require a different brand.

◆Notice

- 1. Please discard the empty used grease cartridge and replace a new one. Do not refill grease into the used grease cartridge.
- 2. Please hold the grease tank tightly to prevent it from popping out by the spring force while disassembling.
- 3. Before replacing a new grease cartridge, lightly squeeze out a little grease in the grease cartridge to prevent air from entering the lubricator.

♦Instruction of Replacing 700cc Grease Cartridge

	◆Instruction of Replacing 700cc Grease Cartridge							
1	Loosen	Hold the grease tank tightly and turn it anticlockwise to disassemble it from the grease tank holder.	5	Tighten	Assemble the new grease cartridge to the grease tank holder by turning it clockwise.			
2	1	Take the grease tank out and put it aside.	6		Assemble the grease tank back to the grease tank holder.			
3	Loosen	Rotate the used grease cartridge anticlockwise to remove it from the grease tank holder and dispose of it properly.	7	Tighten	Rotate the grease tank clockwise to assemble it with the grease tank holder to complete the replacement of the grease cartridge.			
4		Before replacing a new grease cartridge, lightly squeeze out a little grease in the grease cartridge to prevent air from entering the lubricator.						